



# ***SERVICE MANUAL***



## **Models:**

**1480**

**(Serial Numbers- 1000 and above)**

**1481**

**(Serial Numbers- 1000 and above)**

# TABLE OF CONTENTS

Fluido DHT™ Dry Heat Therapy Unit

|                                                   |              |                                                     |              |
|---------------------------------------------------|--------------|-----------------------------------------------------|--------------|
| <b>Foreword</b> .....                             | <b>1</b>     | <b>Diagrams</b> .....                               | <b>23-45</b> |
| <b>Precautionary Symbol Definitions</b> .....     | <b>2</b>     | Base Assembly - 120v and 230v .....                 | 23           |
| <b>Safety Precautions</b> .....                   | <b>3-4</b>   | Control Panel Assembly - 120v and 230 v ....        | 24           |
| <b>Theory of Operation</b> .....                  | <b>5</b>     | Lid Assembly - 120v and 230v .....                  | 25           |
| <b>Nomenclature</b> .....                         | <b>6-7</b>   | Switch Plate Assembly - 120v .....                  | 26           |
| <b>Specifications</b> .....                       | <b>8</b>     | Switch Plate Assembly - 230v .....                  | 27           |
| <b>Troubleshooting</b> .....                      | <b>9-12</b>  | Wiring Diagram - 120v .....                         | 28           |
| Fluido Software Error Messages .....              | 9            | Wiring Diagram - 230v .....                         | 29           |
| Motor/Blower Error .....                          | 9            | Heater Enclosure Assembly - 120v .....              | 30           |
| Temperature Sensor Error .....                    | 9            | Heater Enclosure Assembly - 230v .....              | 31           |
| Fluido System Testing .....                       | 10-12        | Motor & Support Assembly - 120v .....               | 32           |
| Visual Inspection .....                           | 11           | Motor & Support Assembly - 230v .....               | 33           |
| Ground Resistance Test .....                      | 11           | Motor Housing Assembly (1) - 120v .....             | 34           |
| Leakage Tests .....                               | 11           | Motor Housing Assembly (1) - 230v .....             | 35           |
| Resetting Fluido Factory Defaults .....           | 11           | Motor Housing Assembly (2) - 120v .....             | 36           |
| Preheat Test .....                                | 11           | Motor Housing Assembly (2) - 230v .....             | 37           |
| Pulse Mode Test .....                             | 12           | Motor Housing Assembly (3) - 120v .....             | 38           |
| Treatment Time Test .....                         | 12           | Motor Housing Assembly (3) - 230v .....             | 39           |
| Air Speed Test .....                              | 12           | Final Assembly (1) - 120v .....                     | 40           |
| Control Panel Lock-Up .....                       | 12           | Final Assembly (1) - 230v .....                     | 41           |
| <b>Removal &amp; Replacement Procedures</b> ..... | <b>13-20</b> | Final Assembly (2) - 120v .....                     | 42           |
| Sleeves and Cellex .....                          | 13           | Final Assembly (2) - 230v .....                     | 43           |
| Control Panel PC Board .....                      | 13-14        | Final Assembly (3) - 120v .....                     | 44           |
| Fluido Heater .....                               | 15-18        | Final Assembly (3) - 230v .....                     | 45           |
| Fluido Diffuser .....                             | 18           | <b>Warranty</b> .....                               | <b>46</b>    |
| Fluido Motor .....                                | 18-19        | <b>Warranty Repair/Out of Warranty Repair</b> ..... | <b>46</b>    |
| Muffler and Muffler Cover .....                   | 19           |                                                     |              |
| Casters .....                                     | 20           |                                                     |              |
| <b>Replacement Parts</b> .....                    | <b>21-22</b> |                                                     |              |

Read, understand and follow the Safety Precautions and information contained in this manual.

This manual contains the necessary safety, and field service information for those Field Service Technicians, approved by Chattanooga Group, to perform field service on the Fluido DHT Models 1480 and 1481 units.

At the time of publication, the information contained herein was current and up to date. However, due to continual technological improvements and increased clinical knowledge in the field of fluidotherapy, as well as Chattanooga Group's policy of continual improvement, Chattanooga Group reserves the right to make periodic changes and improvements to their equipment and documentation without any obligation on the part of Chattanooga Group.

It is the sole responsibility for field technicians to stay informed and trained in the latest technology utilized in the Fluido DHT Models 1480 and 1481 units by Chattanooga Group. From time to time, as significant improvements are incorporated, Service Bulletins will be produced and made available on our web site ([www.chattgroup.com](http://www.chattgroup.com)) in lieu of reprinting a complete manual prematurely. These Service Bulletins will provide updated service information and technological improvements to the Fluido DHT Models 1480 and 1481 for use by approved service technicians.

#### **"Approved Service Technician" Definitions;**

- 1. Level I-** Those Field Service Technicians that have successfully completed the minimal training required by Chattanooga Group, in basic service techniques.
- 2. Level II-** Those Field Service Technicians that have successfully completed Level I Training as well as Level II Training as required to perform specific troubleshooting and repair techniques and procedures.
- 3. Level III-** Those Field Service Technicians that have successfully completed Levels I & II Training as well as Level III Advanced Training as required to perform all necessary Troubleshooting and Repair techniques. The Technician having successfully completed the three levels of training and coupled with experience should have the ability to train other technicians in Level I and Level II Training with the necessary Training Materials from Chattanooga Group.
- 4. Temporary-** Chattanooga Group, at its discretion and based on known experience of the technician, may grant a "Temporary Approval" to a field technician for particular troubleshooting and repair of a specific unit requiring immediate attention. This "Temporary Approval" in no fashion acknowledges the training level of a technician as defined above. This "Temporary Approval" is utilized only in unique situations for a specific unit for a specific service technique only and is documented as such.

Due to the complex nature of the technology utilized by Chattanooga Group, the recommended troubleshooting techniques for PC Boards are to determine "Bad Board" and PC Board replacement only. No board component level troubleshooting is recommended nor will information or parts be supplied by Chattanooga Group. Any PC Board component level troubleshooting performed will be at sole risk and liability of the Service Technician performing such troubleshooting techniques.

This equipment is to be sold and used only under the prescription and supervision of a licensed medical practitioner.

This equipment is to be serviced only by an "Approved Service Technician".

---

For Additional Service Contact:  
Chattanooga Group  
**DHT Support Department**  
**Toll Free: 1-866-864-0598**  
**Outside USA: +1-423-870-7200**

# SYMBOL DEFINITION

Fluido DHT™ Dry Heat Therapy Unit

The following symbols are located on the Chattanooga Group Fluido DHT Dry Heat Therapy Unit Control Panel. Understand the meaning of each symbol before attempting any operation or use of the unit.



This symbol indicates therapy session Time adjustment.



This symbol indicates therapy session Temperature adjustment.



This symbol indicates therapy session Air Speed adjustment.



This symbol indicates Upward adjustment in function parameters.



This symbol indicates Downward adjustment in function parameters.



This symbol with the illuminated Blue indicator light indicates the Intake Filter requires changing.



This symbol with the illuminated Blue indicator light indicates the Cellex® media requires changing.



This symbol indicates Start therapy session.



This symbol indicates Stop therapy session.



This symbol indicates Pulse Mode for pulse therapy sessions.



This symbol indicates Preheat Standby function.

## Precautionary Symbol Definitions

The precautionary instructions found throughout this manual are indicated by specific symbols. Understand these symbols and their definitions before operating or servicing this equipment. The definitions of these symbols are as follows:



## CAUTION

### CAUTION

Text with a “CAUTION” indicator will explain possible safety infractions that could have the potential to cause minor to moderate injury or damage to equipment.



## WARNING

### WARNING

Text with a “WARNING” indicator will explain possible safety infractions that will potentially cause serious injury and equipment damage.



## DANGER

### DANGER

Text with a “DANGER” indicator will explain possible safety infractions that are imminently hazardous situations that would result in death or serious injury.



### EXPLOSION HAZARD

Do not use this equipment in the presence of flammable anesthetics. This symbol is also prominently displayed on the serial number plate of the unit.

### NOTE:

Throughout this manual “NOTE” may be found. The Notes are helpful information to aid in the particular area or function being described.

## Safety Precautions

Read, understand and follow all safety precautions found in this manual. The following are general safety

precautions that must be read and understood before attempting any service techniques on these units. Throughout this manual, specific safety precautions will be found. Read, understand and follow all safety precautions.



## CAUTION

- Read, understand and practice the precautionary and operating instructions found in this manual. Know the limitations and hazards associated with using any electrical device. Observe the precautionary and operational decals placed on the unit.
- DO NOT operate the unit when connected to any unit other than Chattanooga Group devices.
- Refill unit daily to proper fill level with Chattanooga Group Cellex® Dry Heat Medium.
- Change Cellex Dry Heat Medium every six (6) months.
- Use only Cellex Dry Heat Medium in the Fluidotherapy units.
- Clean Inlet Filter(s) daily before unit startup.
- Use only fingers to operate button controls on the control panel(s). Use of sharp objects such as pencils or pens will result in damage to the unit.
- Turn unit to the “Standby” mode before positioning a patient or removing a patient from the unit.
- After or between treatments, do not immediately unplug or turn the power off from the unit. Allow the unit to process through the “Cool Down” cycle. The unit cycles into standby mode after treatment time has elapsed. Standby can be disabled by pressing the preheat/standby button. The unit goes to a 3 minute cool down mode after standby is turned off. Turning the power off before cool down completes is potentially hazardous to the equipment, and could lead to failure of the unit. It is recommended that power be supplied to the unit at all times. Keep in mind that the recommended treatment air speed is 50%
- Secure all entry ports before turning the unit ON.
- Check unit temperature before treating patient to ensure correct temperature.
- Place the patient in a comfortable position allowing for correct placement of the limb being treated.
- Proper storage and transport temperatures for the Fluido DHT units are 40°F - 158°F (4.5 °C - 70°C). Relative Humidity 85%.
- This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to other devices in the vicinity. However, there is no guarantee that interference will not occur in a particular installation. Harmful interference to other devices can be determined by turning this equipment on and off. Try to correct the interference using one or more of the following: Reorient or relocate the receiving device, increase the separation between the equipment, connect the equipment to an outlet on a different circuit from that to which the other device(s) are connected and/or consult the factory field service technician for help.

## Safety Precautions Continued

### **WARNING**

- Federal law restricts this device to sale by, or on the order of, a physician or licensed practitioner. This device should be used only under the continued supervision of a physician or licensed practitioner.
- For continued protection against fire hazard, replace fuses only with ones of the correct type and rating.
- Make certain the unit is electrically grounded by connecting only to a grounded electrical service receptacle conforming to the applicable national and local electrical codes.
- This device should be kept away from children.
- Care must be taken when operating this equipment around other equipment. Potential electromagnetic or other interference could occur to this or to the other equipment. Try to minimize this interference by not using other equipment in conjunction with it.
- Before administering any treatment to a patient you should become acquainted with the operating procedures for each mode of treatment available, as well as the indications, contraindications, warnings and precautions. Consult other resources for additional information regarding the application of Dry Heat Therapy.
- To prevent electrical shock, disconnect the unit from the power source before attempting any maintenance procedures.
- Use only Cellex® processed dry heat medium in the unit to prevent excessive dusting.
- Adequate precautions should be taken when treating individuals with suspected or diagnosed medical conditions or diseases such as heart problems, epilepsy, diabetes, etc.
- Prior to treatment, consult a medical professional familiar with the precautionary measures to be taken for patients that may experience allergic reactions to dust and pollen.
- Properly dispose of used Cellex according to National and local laws, rules and regulations.

### **DANGER**



- Explosion hazard if used in the presence of flammable anesthetics. The warning symbol for this hazard is prominently displayed on the serial number plate.
- Perform all Required Maintenance as described in this and the User Manual. Strict adherence to the Required Maintenance for the Fluido DHT units is mandatory. Failure to perform the Required Maintenance could result in the Cellex medium entering the heat chamber of the unit(s) and cause severe injury to patients as well as smoke damage to the facility and the Fluido DHT unit(s).
- Make certain the unit is unplugged from the power source before attempting any removal and replacement procedures on the unit.

## THEORY of OPERATION

Fluido DHT™ Dry Heat Therapy Unit

The Fluido DHT utilizes ambient air and pressurizes it via an internal blower. The pressurized air is directed across a heating element bringing the air to the desired treatment temperature. The heated, pressurized air is then diffused across and through a baffle to fluidize and heat the Cellex media in a patient treatment reservoir. All treatment parameters; air speed, temperature, treatment time and the unit preheat settings are programmed by the operator with the touch panel user interface. The Fluido DHT unit base incorporates four locking casters and a manually operated hydraulic lift to adjust height and rotation of the treatment reservoir for patient comfort.




# NOMENCLATURE

Fluido DHT™ Dry Heat Therapy Unit

## Fluido DHT

The nomenclature graphics below, Figure 3.1, indicate the general locations of the major components of the Fluido DHT unit.

Know the components and their functions before performing any operation of or service to the Fluido DHT Model 1480 and 1481 unit.



1. **RESERVOIR LID** - Allows access to the treatment cavity for adding Cellex® medium.
2. **LATCHES** - Secures Reservoir Lid
3. **SIDE ACCESS PORTS** - Four available Side Access Ports. Two on each end of the unit.
4. **RESERVOIR/TREATMENT CAVITY** - Patient treatment cavity and Cellex Reservoir.
5. **TREATMENT LIMB SLEEVES** - Replaceable and launderable patient limb treatment sleeves.
6. **HEAT CHAMBER** - Houses Heating element.
7. **INTAKE FILTER** - Air intake filter. Requires periodic replacement.
8. **LOCKING CASTERS** - Four Locking Casters for securing the unit in place for treatment.
9. **ELEVATION ADJUSTMENT CYLINDER** - Adjusts and maintains reservoir to desired height for patient comfort.
10. **UNIT BASE** - Rigid unit base for ease in transporting unit to different locations for treatment.
11. **HEIGHT ADJUSTMENT PEDAL** - Used to raise, rotate, release and lock the cylinder for height adjustment of the unit.
12. **BLOWER HOUSING** - Houses Blower Motor.
13. **CONTROL PANEL** - Operator Controls. See Page 7 for detail description of each control.
14. **TREATMENT CAVITY VIEWING WINDOW** - View treatment area during treatment.
15. **TOP ACCESS PORT** - Top Treatment access port with sleeve.


# NOMENCLATURE

Fluido DHT™ Dry Heat Therapy Unit

## Fluido Control Panel

The Control Panel nomenclature graphics below, Figure 3.2, indicate the location and functions of the Fluido DHT Model 1480 and 1481 control panel.

Know the components and their functions before performing any operation of or service to the Fluido DHT Model 1480 and 1481 unit.



1. **PANEL DISPLAY-** Displays settings and operational parameters.
2. **TEMPERATURE-** Use in conjunction with the Up and Down arrows to set operation Temperature. Temperature can be adjusted in 1° increments. The available temperature range is 88° F to 130° F (31° C to 54° C).
3. **AIR SPEED-** Use in conjunction with the Up and Down arrows to adjust air speed for fluidization of the Cellex® Medium. Available speeds range from 5% to 100% (in 5% increments).
4. **PULSE MODE-** Turn Pulse Mode On and Off as well as adjust pulse time. Available Pulse Time is from 1 second On/1 Second Off to 6 Seconds On/6 Seconds Off.
5. **UP and DOWN ARROWS-** Use in conjunction with other mode or function buttons to set desired parameters.
6. **PREHEAT STANDBY-** Turn the Preheat Standby Mode On and Off as well as set the parameters desired for the Preheat Standby Mode to automatically start.
7. **TREATMENT STOP-** Press to stop treatment.
8. **TREATMENT START-** Press to start treatment.
9. **CLEAR BUTTON-** Used to turn off maintenance indicators after maintenance has been properly performed.
10. **MEDIA-** Indicator will light when it is time to change the Cellex® Medium.
11. **FILTER-** Indicator will light when it is time to change the required filters.
12. **TIME-** Use in conjunction with the Up and Down arrow buttons to set treatment time. Available time is 1 to 99 minutes, in one minute increments, or Continuous.

# SPECIFICATIONS

Fluido DHT™ Dry Heat Therapy Unit



## Model 1480

MODE OF OPERATION . . . . . Continuous  
OPERATIONAL FUNCTIONS

Variable Adjustments . . . . . Time, Temp and Air Speed  
Pulse Mode . . . . . OFF to 6 Sec ON/OFF  
Available Languages . . . . . English, Spanish and French  
TREATMENT TIME . . . . . 1 to 99 minutes and Continuous  
\*OPERATING TEMPERATURE . 88 °F (31 °C) to 130 °F (54 °C)  
AIR SPEED . . . . . 5% to 100% (5% increments)  
PREHEAT TIMER . . . . . Per default setting with 50% Air Flow  
during 30 min. preheat then 5%  
airflow for standby.

Cellex® MEDIUM CAPACITY . . . . . 20-25 lbs (9-11 kg)  
INPUT POWER . . . . . 120V, 50/60 Hz, 12A  
FUSE RATING . . . . . 10 A Time Delay (Slo-Blow)  
PHYSICAL DIMENSIONS

Unit Depth . . . . . 31" (79 cm)  
Unit Width . . . . . 29.5" (75 cm)  
Overall Height . . . . . 41" - 49" (104 cm - 124 cm)  
Patient Height . . . . . 31" - 39" (79 cm - 99 cm)  
Reservoir Swivel . . . . . 360°  
Weight . . . . . 145 lbs (66 kg)  
Shipping Weight (Including Stool) . . . . . 210 lbs (95 kg)

Electrical: Class I

Type B Equipment

Attention, consult accompanying documentation.  
Ordinary equipment: Not designed to prevent ingress of  
water.

\*Dependent upon airspeed selected

## Model 1481

MODE OF OPERATION . . . . . Continuous  
OPERATIONAL FUNCTIONS

Variable Adjustments . . . . . Time, Temp and Air Speed  
Pulse Mode . . . . . OFF to 6 Sec ON/OFF  
Available Languages . 9 Languages on Board (See Page 10)  
TREATMENT TIME . . . . . 1 to 99 minutes and Continuous  
\*OPERATING TEMPERATURE . 31 °C (88 °F) to 54 °C (130 °F)  
AIR SPEED . . . . . 5% to 100% (5% increments)  
PREHEAT TIMER . . . . . Per default setting with 50% Air Flow  
during 30 min. preheat then 5%  
airflow for standby.

Cellex® MEDIUM CAPACITY . . . . . 9-11 kg (20-25 lbs)  
INPUT POWER . . . . . 230 V~, 50/60 Hz, 10A  
FUSE RATING . . . . . 10 A Time Delay (Slo-Blow)  
PHYSICAL DIMENSIONS

Unit Depth . . . . . 79 cm (31")  
Unit Width . . . . . 75 cm (29.5")  
Overall Height . . . . . 104 cm - 124 cm (41" - 49")  
Patient Height . . . . . 79 cm - 99 cm (31" - 39")  
Reservoir Swivel . . . . . 360°  
Weight . . . . . 66 kg (145 lbs)  
Shipping Weight (Including Stool) . . . . . 95 kg (210 lbs)

Electrical: Class I

Type B Equipment

Attention, consult accompanying documentation.  
Ordinary equipment: Not designed to prevent ingress of  
water.

\*Dependent upon airspeed selected

# TROUBLESHOOTING

Fluido DHT™ Dry Heat Therapy Unit


## Fluido DHT Model 1480 and 1481 Software Error Messages

**A.** The information provided in this section is intended to aid in troubleshooting the Fluido DHT Model 1480 and 1481 units. There are only two software error messages that could indicate a "Bad Board". Therefore, should tests contained in this section indicate the pc board is bad the board must be replaced as an assembly. No component level troubleshooting information is or will be provided by Chattanooga Group for field troubleshooting of pc board components.

**B.** Once the PCB has been determined as bad, replace the suspected board as described in the Removal & Replacement section of this manual.

## Motor/Blower Error

**A.** Should the software detect a problem within the operation of the Blower/Motor, the display will show four dashes beneath "AIRSPEED" on the control panel LCD.




**B.** If this indicator is visible, there could be several possible reasons:

- The intake filters are clogged and require cleaning.
- The motor has overheated and requires a cooling period before operation is resumed.
- The Distributor is clogged and requires changing.
- The Cellex Medium has entered the heat cavity of the unit and is restricting the air flow. Should this indicator be visible, remove the unit from service immediately. Perform any

and all maintenance and repair necessary before the unit is placed back into service. Refer to the appropriate sections of this manual for proper removal and replacement procedures.

## Temperature Sensor Error

**A.** Should the Temperature Sensor experience problems the software will display four dashes beneath "Temp" on the LCD.



Should this occur the system may "Lock Up," preventing any further operation of the unit. This error could be caused by several different problems including:

- The intake filters are clogged and require cleaning.
  - The Temperature Sensor is faulty and requires replacement.
  - The Distributor is clogged and requires changing.
  - The Cellex Medium has entered the heat cavity of the unit and is restricting the air flow.
- B.** Reset the Temperature Sensor by turning the unit Off. Press and hold the "Stop" button for ten to fifteen seconds. Release the "Stop" button and turn the unit On. It will be necessary to reset the Clock (refer to Users Manual). If the Error persists, remove and replace the Temperature Sensor. If the problem continues to persist, replace the pc board in the control panel. Refer to the appropriate section of this manual for proper removal and replacement procedures.

## Fluido DHT System Testing

### A. General

1. The following information is intended to aid in troubleshooting the major components of the DHT Units to "Board Level" only. These tests are OEM standard testing procedures and methods used at the factory before shipment of any Fluido unit.
2. Due to the complex nature of the technology utilized by Chattanooga Group, the recommended troubleshooting techniques are to determine "Bad Board" and board replacement only. No board component level troubleshooting is recommended nor will information or parts be supplied by Chattanooga Group. Any board component level troubleshooting performed will be at sole risk and liability of the Service Technician performing such troubleshooting techniques.
3. Once the PC Board has been determined as bad, replace the board only with Chattanooga Group OEM replacement parts and hardware.

### B. Special Tools, Fixtures & Materials Required

1. Certain tests require the use of special tools and fixtures. These will be listed at the particular test where they are required. Testing with any other special tool or fixture other than those stated could give erroneous readings or test results. Always perform the tests exactly as stated to ensure accurate results.
2. Standard test equipment settings will be listed for each test performed to aid in performing the test to OEM standards and ensure proper readings.
3. The troubleshooting and repair of the Fluido DHT units, should be performed only by authorized technicians trained and certified by Chattanooga Group.

### C. Equipment Required

1. Digital Multimeter
2. Dielectric Withstand (Hi-Pot) and ground resistance tester.
3. Milliohm Meter.
4. Calibrated Thermometer
5. Calibrated Stop Watch

#### NOTE:

Adjust Dielectric Withstand tester to indicate fault with 120k Ohm Load across the output when at specified test voltage.



## CAUTION

The following tool, lubrication, and sealing compound requirements are critical to the component removal and replacement of the Fluido DHT unit.

All hardware, bolts, nuts and screws used to assemble the Fluido DHT are SAE Standard. Due to the size of these components no metric equivalent is available. Therefore, it will be necessary to obtain the proper size tools for removal and replacement of certain components.

The lubricants and sealing compounds listed below are crucial in the assembly of certain components to ensure patient safety and efficient operation of the unit. Use only the recommended products listed or an approved equivalent possessing the same properties and qualities.

### 6. Required SAE Tools

#1 Phillips Screwdriver  
#2 Phillips Screwdriver  
5/16, 7/16, 9/16, 1/2, 5/32, and 11/32 Wrenches  
1/8 and 5/32 Allen Wrenches (or drill bits)  
Utility Knife  
Wet/Dry Vacuum

### 7. Required Lubricants

Silicon based multipurpose grease.

### 8. Required Sealing Compound

100% pure silicon sealant

#### NOTE:

The tool, lubricant and sealing compound requirements will be listed at the respective removal and replacement procedures throughout this manual.

## Visual Inspection

### A. General

Visually inspect the Fluido DHT unit. A visual inspection can, to an experienced Technician, indicate possible abuse of the unit and/or internal problems.

## Ground Resistance Test

### A. Voltage Specifications

**Model 1480** . . . . . Input: 120 VAC~50/60 Hz, 40 Watts

**Model 1481** . . . . . Input: 230 VAC~50/60 Hz, 40 Watts

### B. Specification

Maximum Acceptable Resistance: 500 milliohms

### C. Equipment Required

Milliohm Meter

### D. Test


Place unit on level work surface.

Place one meter probe on the ground prong of power cord and the other to any exposed metal or screw on the unit.

## Leakage Tests

**Test Voltage Spec** . . . . . 1000V

Conduct all necessary leakage tests as required per "Chapter 7 Electrical Equipment" of the 1999, or later, edition of the NFPA (National Fire Protection Association) "Health Care Facilities" standards.



## WARNING

UNIT FAILING DIELECTRIC WITHSTAND AND/OR LEAKAGE TESTS COULD INDICATE SERIOUS INTERNAL SYSTEM PROBLEMS.

DO NOT PLACE UNIT BACK INTO SERVICE! SEND UNIT TO FACTORY FOR REPAIR!

DO NOT ATTEMPT TO REPAIR IN THE FIELD!

## Resetting Fluido DHT Factory Default Settings

To reset all factory default settings of the unit, turn unit Off. Depress and hold the "Clear" button on the control panel and turn unit on simultaneously.

## Preheat Test

### A. Tools & Equipment Required

Calibrated Thermometer

### B. Preheat Test Procedures


#### Power Requirements:

Model 1480. . . . . 120 VAC

Model 1481. . . . . 230 VAC

Plug the unit power cord to a grounded electrical service receptacle conforming to the applicable national and local electrical codes.

Turn unit power switch On.



Start the preheat function by depressing the "PREHEAT STANDBY" button on the control panel. After approximately 30 seconds, the Blue LED should illuminate.

After approximately 30 minutes or less, depending on the ambient temperature of the medium, the blower should reduce from 50% airspeed to 5% airspeed and the Temp indicator should read the temperature of the Cellex® medium. Insert the calibrated thermometer into medium and record the reading. The Temperature reading should be  $\pm 5^{\circ}\text{F}$  or  $3^{\circ}\text{C}$  of Spec below.

**Preheat Default Temp. Spec** . . . . 115  $^{\circ}\text{F}$  (46.11  $^{\circ}\text{C}$ )

A temperature reading outside the specified range may be caused by clogged intake filters, clogged distributor, faulty temperature sensor, or faulty heating element. Refer to the appropriate section for the proper removal and replacement procedures.

## Pulse Mode Test

### A. Tools & Equipment Required

Calibrated Stop Watch

### B. Pulse Mode Test Procedures

Reset the factory defaults. Refer to the section entitled "Resetting Fluido DHT Factory Default Settings" on page 11.

Press the "PULSE MODE" button, the Blue LED should illuminate. Press the "TREATMENT START" button.

Using the calibrated stop watch, time the pulses of the unit while it is running. Record the readings taken and verify the settings you entered for the pulse.

The unit should pulse at approximately four seconds on, after reaching its maximum blower speed, and four seconds off.

## Treatment Time Test

### A. Tools & Equipment Required

Calibrated Stop Watch

### B. Treatment Time Test

With the unit On, press and release the "Time" button. Using the down arrow, adjust the time to "1:00".

Press "TREATMENT START" and time with the Calibrated Stop Watch. Record the reading.

**Treatment Time Spec** . . . . . 1 minute  $\pm$  1 second

## Air Speed Test

### Airspeed Test Procedures

Turn unit On. Press "Treatment Start". While unit is running, press the "Air Speed" button. Use the Up and Down arrows to adjust the air speed to 100% and back down to 5%. Listen for the increase and decrease in the blower speed. Look for increased and decreased fluidization of the medium in the reservoir.

## Control Panel Lock-Up

Should the control panel Lock Up and not allow any operation of the unit or parameter changes. Reset the unit Factory Defaults (Refer to the section entitled "Resetting Fluido DHT Factory Default Settings" on page 11). If the condition persists, replace the Control Panel PC Board. Refer to "Control Panel PC Board" on page 13 for removal and replacement procedures.

## NOTE:

For proper operation and setting of the unit parameters outside the Factory Defaults, refer to the User Manual for the Fluido DHT.

# REMOVAL & REPLACEMENT

Fluido DHT™ Dry Heat Therapy Unit

Sleeves and Cellex®

## **WARNING**

UNPLUG THE UNIT FROM THE POWER SOURCE BEFORE ATTEMPTING ANY REMOVAL OR REPLACEMENT PROCEDURES TO PREVENT ELECTRICAL SHOCK. FOLLOW ELECTRONIC REPAIR PROTOCOLS FOR GROUNDING TO PREVENT DAMAGE TO THE ELECTRONIC COMPONENTS FROM STATIC ELECTRICITY.

Refer to the Fluido DHT User Manual for the proper removal and replacement of the following items:

Unit End Sleeves

Unit Top Sleeves

Cellex Medium

Intake Filters

### Control Panel PC Board

#### A. Tools & Equipment Required

Small Flat Blade Screwdriver

5/16 Open End Wrench

#2 Phillips Screwdriver

#### B. Removing the Control Panel PC Board

1. Remove the three retaining screws from the Control Panel Bezel.



2. Carefully remove the Bezel from the Control Panel.



3. Remove the four retaining nuts securing the Control Panel to its mounting base (two on each side).



4. Remove the Control Panel from the mounting base.



5. Remove the five wiring harnesses from the PC Board.



## C. Replacing the Control Panel PC Board

To replace the control panel PC board, reverse steps 1 through 7 of "Removing the Control Panel PC Board" starting on page 13.

**NOTE:** Keep in mind the following when replacing the Control Panel PC Board:

- Attach the connector with the two brown wires to the heater terminal.
- Attach the connector with one brown wire and one blue wire to the line terminal.
- Attach the connector with one black wire and one white wire to the motor.
- Attach the small, three- wire connector wires to the speed terminal.
- Attach the small, two-wire connector to the temperature terminal.

# REMOVAL & REPLACEMENT

Fluido DHT™ Dry Heat Therapy Unit

## Fluido Heater

### A. Tools Required

Wet/Dry Vacuum    1/8 Allen Wrench  
7/16 Wrench        #1 Phillips Screwdriver  
Wire Cutters       Hammer


### B. Removing the Fluido Heater

1. Remove lid completely from unit.
2. Using the wet/dry vacuum, remove the Cellex from the tub.
3. Remove the seven screws from the perforated metal at the bottom of the tub.



## CAUTION

Make certain to vacuum the screw heads at the base of the tub. This will ensure that Cellex will not fall in the standoff's holes, and you will not round out the heads of the screws when re-inserting them.



4. Using the wet/dry vacuum, remove the newly exposed, excess Cellex.

**NOTE:** When vacuuming, be careful not to damage the temperature sensor.



5. Remove the rubber tub insert closest to the control panel. Then, remove the other rubber tub insert.



6. Using the wet/dry vacuum, remove the newly exposed, excess Cellex.



## CAUTION

Make sure to remove the excess Cellex from the heads of the hex screws to avoid rounding out the heads of the screws.


7. Remove the ten hex screws from the bottom of the tub.




## REMOVAL & REPLACEMENT

Fluido DHT™ Dry Heat Therapy Unit

8. Cut and remove the plastic band securing the temperature sensor.



9. Remove the perforated metal.  
10. Remove the diffuser baffle.  
11. Remove the diffuser foam.




### CAUTION

Make certain that you do not spill any Cellex into the heater enclosure cavity.

12. Remove bottom (and final) piece of perforated metal.

13. Using the screwdriver, remove the ground screw.



14. Follow steps 1-3 listed in "Removing the Muffler Cover and Muffler" on page 19.


15. Remove the two hex screws from the motor support bracket.



## REMOVAL & REPLACEMENT

Fluido DHT™ Dry Heat Therapy Unit


16. Using a 7/16 wrench, remove the five hex nuts from the heater housing, as well as the motor support bracket.




17. Use the claw end of the hammer to gently and slightly pull up the edge of the unit in order to get clearance for the overtemp sensor.



18. Slide the heater assembly out.




19. Using wire cutters, cut the wire between the brown and black wires.



20. Unplug the dark blue wire from the inlet side of the line filter.



21. Using the wire cutters, cut the black heater indicator light wire from the switch plate assembly.



# REMOVAL & REPLACEMENT

Fluido DHT™ Dry Heat Therapy Unit


## C. Replacing the Fluido Heater

**NOTE:** Before attempting to replace the Fluido heater, Vacuum any loose Cellex that may be in the motor housing or heater housing.

To replace the Fluido heater, reverse steps 1 through 21 of "Removing the Fluido Heater" on pages 15-17 (i.e., instead of cutting wires, simply solder or reattach them).

**NOTE:** When replacing the Fluido heater, be sure to use a new diffuser (14119).

2. With one hand, hold the motor while using your other hand to disconnect the motor wiring from the harness. See the following 2 figures.



## Fluido Diffuser

### A. Tools Required


Wet/Dry Vacuum    #2 Phillips Screwdriver  
Wire Cutters        7/16 Wrench

### B. Removing the Fluido Diffuser

To remove the Fluido diffuser, following steps 1 - 13 of "Removing the Fluido Heater" on pages 15-16.

### C. Replacing the Fluido Diffuser

To replace the Fluido diffuser, reverse steps 1 through 13 of "Removing the Fluido Heater" on pages 15-16.



## Fluido Motor

### A. Tools Required

#2 Screwdriver

### B. Removing the Fluido Motor


Before attempting to remove the Fluido motor, you must complete steps 1 through 3 of "Removing the Muffler and Muffler Cover" on page 19.

1. Remove the five screws outside of the motor support plate, being sure to hold the plate while removing the last screw.




## CAUTION

Hold the motor support plate before removing the last screw. Otherwise, the motor may fall from the housing.



## CAUTION

Be careful not to damage the metal shaft on the end of the motor. See the following figure.



# REMOVAL & REPLACEMENT

Fluido DHT™ Dry Heat Therapy Unit

## C. Replacing the Fluido Motor

To replace the Fluido Motor, reverse steps 1 and 2 of "Removing the Fluido Motor" on page 18.

## Muffler and Muffler Cover

### A. Tools Required

1/8 Allen Wrench

### B. Removing the Muffler Cover and Muffler

1. Remove the 14 screws that secure the muffler cover.



2. Slide the muffler cover down on the shaft.



3. Remove the foam insert from inside the muffler cover.

**NOTE:** Notice the hole in the foam insert. You will need to line up this hole with the Morris taper on the shaft when you re-assemble the muffler.



### C. Replacing the Muffler Cover and Muffler

To replace the muffler and muffler cover, reverse steps 1-3 of "Removing the Muffler Cover" on this page.


## Casters

### A. Materials and Tools Required

- 9/16 Wrench
- (4) Caster - 14135
- Base Frame- 14104
- (4) 3/8-16 Black Acorn Nuts - 14146

### B. Removing the Casters

1. Make sure casters are locked by pressing the metal flap until the wheel does not move. This will prevent the shaft of the caster from moving while you are attempting to remove it.



2. Remove each of the four 3/8-16 black acorn nuts.
3. Lift the base to remove each of the shafts of the four casters from the unit.

### C Replacing the Casters

1. Make sure caster is locked before attempting to install.
2. Place one caster on each corner of the base, and attach with four 3/8-16 black acorn nuts.

# REPLACEMENT PARTS

Fluido DHT™ Dry Heat Therapy Unit

| PART NO. | DESCRIPTION                           |
|----------|---------------------------------------|
| 14105    | BASE ASSEMBLY FLUIDOTHERAPY           |
| 14111    | PATIENT TUB LID FLUIDO DHT            |
| 14113    | LID LATCH FLUIDO DHT                  |
| 14116    | SCREW #2 X 3/8 PAN HD. PHIL.          |
| 14117    | DISTRIBUTOR PLATE FLUIDO DHT          |
| 14118    | PLEXIGLASS TRIM FLUIDOTHERAPY         |
| 14119    | FOAM DISTRIBUTOR PLATE FLUIDOTHERAPY  |
| 14120    | TUB DRAIN PLUG FLUIDOTHERAPY          |
| 14122    | 6-32 X 1/2 OD X1 LG CERAMIC STD. OFF  |
| 14123    | 6-32 X 1/2 OD X 1-1/2 LG CERAMIC STD. |
| 14124    | GASKET TUB LID FLUIDOTHERAPY          |
| 14125    | MANUAL USER FLUIDOTHERAPY             |
| 14128    | MANUAL SERVICE FLUIDOTHERAPY          |
| 14130    | SLEEVE ASSEMBLY FLUIDO DHT            |
| 14135    | CASTER TENTE 006874 FLUIDO DHT        |
| 14136    | FOAM MUFFLER FLUIDO DHT               |
| 14137    | MUFFLER COVER FLUIDO DHT              |
| 14139    | BOTTOM W/ MOTOR HOUSING FLUIDO DHT    |
| 14145    | U.I. DISPLAY LENS FLUIDO DHT          |
| 14146    | ACORN NUT FLUIDO DHT                  |
| 14148    | SCREW 10-32 x 3/4 BUTT. HD. SOC       |
| 14150    | SCREW 10-32 X 1 BUTT HD SOC           |
| 14151    | SWITCH PLATE GASKET FLUIDO DHT        |
| 14160    | SCREW 10-32 X 1/2 BUTT HD SOC         |
| 14161    | HEX STANDOFF 6-32 X .875 ALUM.        |
| 14162    | MULIT STACK ADAPTER                   |
| 14166    | USER INTERFACE COVER FLUIDO DHT       |
| 14168    | PLASTIC COVER FLAT FLUIDO DHT         |
| 14169    | SLEEVE RETAINING CLIP FLUIDO DHT      |
| 14170    | POWER CORD FLUIDO DHT                 |
| 14171    | SWITCH PLATE FLUIDO DHT               |
| 14174    | GASKET MOTOR MOUNTING PLATE           |
| 14175    | ELBOW SLEEVE FLANGE FLUIDO DHT        |
| 14184    | TOP HEATER SHIELD METAL               |
| 14185    | BOTTOM HEATER SHIELD METAL            |
| 14188    | SPONGE GASKET 3/4" X1/4" ADHES.       |
| 14189    | HARNESS CONTROL POWER SWITCH          |
| 14202    | HARNESS CONTROL TO HEATER SUB         |
| 14203    | HARNESS HEATER TO INDICATOR           |
| 14204    | HARNESS FUSE TO RECEPTACLE            |


| PART NO. | DESCRIPTION                                  |
|----------|----------------------------------------------|
| 14206    | HARNESS RECEPTACLE TO POWER SWITCH           |
| 14207    | HARNESS O.T. TO STAT H.E.                    |
| 14208    | HARNESS MOTOR SPEED CONTROL                  |
| 14209    | LINE FILTER BRACKET                          |
| 14211    | HARNESS CONTROL INTERCONNECT                 |
| 14213    | HARNESS GROUND 7"                            |
| 14214    | HARNESS GROUND 24"                           |
| 14215    | HARNESS TEMP SENSOR                          |
| 14219    | 1/4-20 X 5/8 SANDWICH MOUNT                  |
| 14220    | 10 x 24 INSULATION MOTOR HOUSING             |
| 14221    | 5' X 4" INSULATION MOTOR HOUSING             |
| 14222    | 5" X 5" INSULATION MOTOR HOUSING             |
| 14223    | 9" X 9" INSULATION MOTOR HOUSING             |
| 14225    | HARNESS FUSE TO POWER SWITCH 220V            |
| 14226    | HARNESS POWER SWITCH TO LINE FILTER          |
| 14227    | HARNESS O.T. STAT TO H.E.                    |
| 14228    | HARNESS LINE FILTER GROUND TO CHASSIS        |
| 14229    | ELBOW SLEEVE ASSEMBLY                        |
| 14230    | INLET FILTER 19155K22                        |
| 14231    | FILTER NYLON MESH 3-5/8" SQ.                 |
| 14232    | GLIDE ETS 32 X 50 D80153                     |
| 14233    | USER INTERFACE BRACKET PAINTED               |
| 14234    | MOTOR HOUSING SUPPORT PAINTED                |
| 14235    | FOAM INSERT                                  |
| 14236    | MOTOR SUPPORT PLATE PAINTED                  |
| 14237    | SET SCREW 6-32 X 3/4 91375A151               |
| 14238    | SPACER NYLON 1/2 ODX1/4 ID x 5/8 94639A143   |
| 14239    | SCREW #1 X 3/8" 90253A033                    |
| 14240    | POP RIVET 1/8 X 5/8 ALUMINUM 97447A135       |
| 14241    | CAPTIVE STUD 6/32 X 3/8 93580A016            |
| 14244    | RIVNUT 10-32 S10P175                         |
| 14245    | STRAIN RELIEF PLATE FLUIDO DHT               |
| 14247    | 230V. MOTOR HOUSING ASSY.                    |
| 14251    | HYDRAULIC LIFT (CHROME) 4500                 |
| 14253    | FUSE HOLDER SCHURTER                         |
| 14254    | INLET AC FAST CONNECT                        |
| 14255    | 10 AMP. 5MM X 20MM (FUSE)220V 3 AG SLOW BLOW |
| 14259    | 2-56 X 1/4" PAN HD.PHIL PLT.                 |
| 14260    | MOTOR ASSY. 120V.                            |
| 14261    | MOTOR ASSY. 230V.                            |

# REPLACEMENT PARTS


Fluido DHT™ Dry Heat Therapy Unit

| PART NO. | DESCRIPTION                                         |
|----------|-----------------------------------------------------|
| 14262    | HARNESS RECP. TO SWITCH PLATE                       |
| 14263    | HARNESS RECP. GROUND TO GROUND                      |
| 14265    | 1000 watt 110 volt heater                           |
| 14266    | 1000 watt 220 volt heater                           |
| 14268    | TOP DIFFUSER FLUIDO DHT                             |
| 14269    | DIFFUSER AIR BAFFLE FLUIDO DHT/24 ga. carbon        |
| 14270    | DIFFUSER AIR BAFFLE FLUIDO DHT/adhesive backed foil |
| 14272    | HOUSING BRACE SPACER                                |
| 14274    | HOUSING BRACE(PAINTED #)                            |
| 14275    | FOAM INSERT                                         |
| 14276    | POWER SWITCH                                        |
| 14277    | ADAPTER 1/8 NPT 15090-1                             |
| 14279    | heater indicator light blue 230v                    |
| 14284    | HEATER ENCLOSURE ASSY 120V.                         |
| 14285    | POP RIVET 1/8"                                      |
| 14286    | FICHE PAPER 10 MIL THK.                             |
| 14287    | FITTING ADAPTER 1/8 TO 10-32 15090-1                |
| 14288    | heater indicator light blue 120v                    |
| 14291    | Thermal over temp switch                            |
| 14293    | GALVANIZED WIRE CLOTH 6X6 MESH .120 WIRE DIA.       |
| 14294    | HEATER INCLOSURE MESH                               |
| 14295    | HEATER ENCLOSURE ASSY 230V.                         |
| 14296    | MOTOR HOUSING HEATER SCREEN                         |
| 14299    | CONTROL PNL.ASSY 120V                               |
| 14300    | MOTOR ASSY 230V.                                    |
| 14301    | MOTOR ASSY 120V.                                    |
| 14302    | Motor housing warning label                         |
| 14304    | 1" Almn Standoff                                    |

## Base Assembly - 120v and 230v



## Control Panel Assembly - 120v and 230v




### NOTE:


(1) SET SELECTOR SWITCH  
FOR DESIRED VOLTAGE.  
115V. OR 230V.

(2) FOR 115V. USE FUSE #71552.  
FOR 230V. USE FUSE #20656.


## Lid Assembly - 120v and 230v



## Switch Plate Assembly - 120v




## Switch Plate Assembly - 230V




## DIAGRAMS

## DIAGRAMS


## Wiring Diagram - 120v




## Wiring Diagram - 230v




## Heater Enclosure Assembly - 120v




## Heater Enclosure Assembly - 230v




## Motor & Support Assembly - 120v




## Motor & Support Assembly- 230v




## Motor Housing Assembly - 120v




## Motor Housing Assembly - 230v




## Motor Housing Assembly - 120v




## Motor Housing Assembly - 230v




## Motor Housing Assembly - 120v




## Motor Housing Assembly - 230v




## Final Assembly - 120v





## Final Assembly - 230v




## Final Assembly - 120v




## Final Assembly - 230v



## Final Assembly - 120v



## Final Assembly - 230v



# WARRANTY

Fluido DHT™ Dry Heat Therapy Unit

Chattanooga Group ("Company") warrants that the Fluido DHT units ("Product") are free of defects in material and workmanship. This warranty shall remain in effect for two years (24 months) from the date of original consumer purchase. If this Product fails to function during the two year warranty period due to a defect in material or workmanship, Company or the selling dealer will repair or replace this Product without charge within a period of thirty (30) days from the date on which the Product is returned to the Company or the dealer.

All repairs to the Product must be performed by a service center authorized by the Company. Any modifications or repairs performed by unauthorized centers or groups will void this warranty.

The warranty period for replaceable intake filter(s) is 90 days.

The warranty period for sleeves is one year (12 months).

To participate in warranty coverage, this Product's warranty registration card (included with Product) must be filled out and returned to the Company by the original owner within ten (10) business days of purchase.

This Warranty Does Not Cover:

Replacement parts or labor furnished by anyone other than the Company, the selling dealer or a certified Company service technician.

Defects or damage caused by labor furnished by someone other than Company, the selling dealer or a certified Company service technician.

Any malfunction or failure in the Product caused by product misuse, including, but not limited to, the failure to provide reasonable and required maintenance or any use that is inconsistent with the Product User's Manual.

## **COMPANY SHALL NOT BE LIABLE IN ANY EVENT FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.**

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

To Obtain Service From Company or the selling dealer under this warranty:

1. A written claim must be made within the warranty period to the Company or the selling dealer. Written claims made to the Company should be sent to:

4717 Adams Road  
P.O. Box 489  
Hixson, TN 37343 US  
Telephone: (423) 870-2281  
Tel (International): +1 (423) 870-7200  
Facsimile: (423) 870-7200  
Fax (International): +1 (423) 870-2046

and

2. The Product must be returned to the Company or the selling dealer by the owner.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

The Company does not authorize any person or representative to create for it any other obligation or liability in connection with the sale of the Product. Any representation or agreement not contained in the warranty shall be void and of no effect.

## **THE FOREGOING WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.**

When the Fluido DHT unit requires service, or preventive maintenance, contact the selling dealer or Chattanooga Group Service Department.

All units returned to the factory for service must include the following;

### **WARRANTY REPAIR/OUT OF WARRANTY REPAIR**

1. Written statement containing the following information;
  - RGA Number- Obtain from Factory
  - Unit Model Number
  - Unit Serial Number
  - Contact person with Phone and Fax Numbers
  - Billing Address (for Out of Warranty Repair)
  - Shipping Address (Where to Ship Unit after Repair)
  - Detailed Description of Problem or Symptoms
2. Copy of original invoice issued at purchase of the unit.
3. Ship unit to Factory in the original container with all accessories and information as required in item 1 above to:

Chattanooga Group  
4717 Adams Road  
Hixson, TN 37343  
Phone: US: 1-800-592-7329  
Canada: 1-800-361-3661  
Outside US: +1-423-870-7200  
FAX: 1-423-875-5497  
FAX (International): +1-423-870-2046  
Web Address: [www.chattgroup.com](http://www.chattgroup.com)

Service to these units should be performed only by Service Technicians Certified by Chattanooga Group.

## More Trusted Products from Chattanooga Group

### **Achiever™**

Supports

### **Fluido DHT®**

Dry Heat Therapy Units

### **A.E.R. Boot® and Compression System**

Auto Edema Reduction Boot

### **Baseline® Measurement Instruments**

Dynamometers, Goniometers, etc.

### **boo-boo pac™**

Child Size Bear-Shaped Cold Pack

### **Cambion®**

Shock Dampening Foot Care Products

### **Carpal-Trac™**

Carpal Traction Accessory

### **Cervical Traction System**

Clinical Cervical Traction

### **Chattanooga Exerciser™**

Exercise Equipment

### **ColPaC®**

Chilling Units and Reusable Cold Therapy Products

### **Conductor Gel™**

Highly Conductive Ultrasound Gel

### **Contracture Products**

Contracture Management Orthotic Products

### **CTS™**

Carpal Tunnel Stretching Device

### **DURA-STICK® Electrodes**

Self-Adhesive Electrodes

### **EMG Retrainer® and EMG Retrainer® IR**

Dual Channel Surface EMG

### **FlexiPAC®**

Reusable Hot and Cold Compresses

### **Fluidotherapy**

Dry Heat Whirlpool Therapy Units

### **FORTE™ CPS**

Electrotherapy Equipment

### **Gel Medex™**

Gel Mattress Overlay

### **HANDISIZER™**

Hand Exerciser

### **Hydrocollator®**

Heating Units and HotPacs™

### **Intellect® Legend**

Ultrasound and Electrotherapy Products

### **Magneciser™**

Exercise Equipment

### **Myossage®**

Massage Lotion

### **Nylatex®**

Elastic Wraps

### **OptiFlex® and OptiFlex® S**

Continuous Passive Motion

### **Opti-Ice™**

Cold Therapy System

### **Para-Care®**

Paraffin Wax Unit and Accessories

### **Pillow Perfect™**

Cervical Pillow Line

### **Pivotal Therapy System™**

Orthotics for the Spine

### **ProPower Pillow™**

Power Massage Pillow

### **PresSion®**

Intermittent Compression

### **Pron Pillo®**

Positioning Pillow

### **QuikWrap™**

Deluxe Universal Belt System

### **SensaFlex™**

Hot and Cold Compress

### **SPORT-PAC™**

Soccer Ball Shaped Cold Pack

### **Theratherm™**

Digital Moist Heating Pad

### **Therma-Wrap™**

Hot and Cold Compression

### **Triton®**

Treatment and Traction Equipment

### **Tru-Trac®**

Traction Equipment

### **TX®**

Treatment and Traction Equipment

### **Vectra™ Series**

Electrotherapy products.

### **Versa Bath Seat™**

Aid to Daily Living

### **Wellness 1st™**

Back Support

### **Women's Contour Back Support**

Back Support



ISO 13485 CERTIFIED

4717 Adams Road  
P.O. Box 489  
Hixson, TN 37343 U.S.A.  
1-423-870-2281  
1-800-592-7329 U.S.A.  
1-800-361-6661 CANADA  
+ 1-423-870-2046 OUTSIDE U.S.A. FAX  
[www.chattgroup.com](http://www.chattgroup.com)

31971A

© 2003 Encore Medical